




# SOUNDMASK SYSTEM ZONE LAYOUT EXAMPLE


RANDOM DIGITAL NOISE GENERATOR [SM-GR-3100](#)



ZONE DISTRIBUTOR [SM-DR-5000](#)



CEILING TRANSDUCER [SM-T-1200](#)



- NOTES**
- › The [SM-DR-5000](#) is capable of servicing up to 100 transducers for each generator.
  - › Diagram not to scale.



[megan@soundmask.com.au](mailto:megan@soundmask.com.au)



[www.soundmask.com.au](http://www.soundmask.com.au)



1300 734 168 (within Australia)



+61 3 9879 5355